




Navigate smart

# SOFTWARE INSTALLATION MANUAL

### **/01 GETTING STARTED**



### Plug into your computer


- The dongle
- 2 The USB key

The first time, it will take a few minutes for the computer to recognize the hardware

# **/02 INSTALL YOUR ADRENA SOFTWARE**

#### What to do?

- Go to your USB key and open the folder
   Adrena Software > English
- Double click on the file called "AdrenalnstVXX.msi"
- If you don't have the USB key, click **here** to download the software directly



# /02 INSTALL YOUR ADRENA SOFTWARE


Follow the procedure, always using the default values

> Next

- > Next
- > Finish

Adrena software installation is now finished!

### 103 LAUNCH ADRENA SOFTWARE




#### What to do?

Double-click on the icon created on your desktop




Your software is installed!




### **JO5 CONFIGURE CONNECTIONS**

You will be able to receive navigation data from your control unit, GPS data and AIS information

- The **dongle** must be connected to the computer
- Open **Adrena** software
- Follow this path:





#### **JO5 CONFIGURE CONNECTIONS**


#### **Further information**

• For a full description of the different **connection parameters**, press the F1 shortcut key or follow the path below:



Don't forget to validate the General Settings window to take account of the changes you have made





## **706 MINIMUM RECOMMENDED CONFIGURATION**

- A computer with **Windows 7** or higher
- Minimum screen size 1980X1024
- NMEA 0183 connection via serial port or network
- USB port Dedicated to the dongle
- Graphics memory: min. **256 MB**
- Minimum 1.5 GHz multi-core processor
- RAM: 4 GB minimum, 8 GB recommended
- Available disk space: 2 to 4 GB

A multi-core processor will reduce routing calculation time



